

PAW-DHW100W / PAW-DHW150W

| Index | Designation | Code SAV | Code PF | |
|-------|------------------------------------|----------|---------|------|
| | | | 100W | 150W |
| 01 | FRONT COVER | 22807 | X | X |
| 02 | TOP COVER | 22814 | X | X |
| 03 | AIR GRID | 22815 | X | X |
| 04 | REAR COVER | 22808 | X | X |
| 05 | HEATING ELEMENT 1200W | 36535 | X | |
| | HEATING ELEMENT 1600W | 36536 | | X |
| 06 | TOP COMPRESSOR INSULATION | 29680 | X | X |
| 07 | COMPRESSOR INSULATION | 29679 | X | X |
| 08 | HEAT PUMP | 29740 | X | X |
| 09 | FAN SCROLL CASING | 22817 | X | X |
| 10 | FAN | 22816 | X | X |
| 11 | COLUMN 100L | 22809 | X | |
| | COLUMN 150L | 22810 | | X |
| 12 | HMI INTERFACE | 29689 | X | X |
| 13 | FAN CAPACITORS (1,5µF-2,5µF-2,7µF) | 29681 | X | X |
| 14 | CONTROLLER BOARD PCB 100L | 29698 | X | |
| | CONTROLLER BOARD PCB 150L | 29699 | | X |
| 15 | BOTTOM CAP | 22266 | X | X |
| 16 | LOWER COLUMN CAP | 22813 | X | X |
| 17 | WATER SENSOR WIRE | 26337 | X | X |
| 18 | HEAT PUMP WIRE SENSOR | 26336 | X | X |
| 19 | HMI WIRE | 26335 | X | X |
| 20 | ELEC BACKUP WIRE | 26341 | X | X |
| 21 | COMPRESSOR WIRE | 29686 | X | X |
| 22 | MAIN ELECTRICAL SUPPLY WIRE | 26338 | X | X |
| 23 | RUN CAPACITOR 10µF | 29682 | X | X |
| 24 | ELEMENT SCREW | 26063 | X | X |
| 25 | ELEMENT NUT | 26064 | X | X |
| 26 | ANODE | 40164 | X | X |
| 27 | LIP GASKET | 99060 | X | X |

